

TRUPOSEPT[®] BA

bactericide

| | |
|--------------------|---------------------------|
| Appearance: | yellowish liquid |
| Basis: | organic sulphur compounds |
| pH value (1 : 10): | approx. 10 |

Properties:

TRUPOSEPT BA is an effective and safe bactericide. It is rapidly and uniformly absorbed by the skin surface.

TRUPOSEPT BA is extremely well suited for application during soaking and for short-term preservation (up to 5 days maximum).

TRUPOSEPT BA is a low-odour product. It should be used within pH range 5 - 10.

TRUPOSEPT BA is compatible with other soaking auxiliaries (e.g. **TRUPOWET[®]** products).

Application:

Soaking:

0.05 - 0.1 % **TRUPOSEPT BA** (calculated on fresh or salted weight) is sufficient for a short soaking of 4 - 6 hrs.

0.1 - 0.2 % are usually applied for soaking overnight. The product is added at the beginning of soaking.

Short-term preservation:

A short-term preservation is usually required to preserve raw material over a week-end. Prior to the short-term preservation, washing should be carried out to remove dirt, dung and residual blood.

Then the preservation procedure (e.g. in drum) follows with 100 – 120 % water, 18 - 20 °C, plus 0.3 % **TRUPOSEPT BA**, run 45 - 60 mins., leave automatic with running 1 – 2 mins. every 2 – 3 hours.

This quantity (0.3 %) is sufficient for a preservation period up to three days under normal climatic conditions.

Should a longer preservation period be required quantities of **TRUPOSEPT BA** to be used have to be adjusted (plus 0.1 % per day!). Five days should not be exceeded.

Skins can be taken out of the drum approx. one hour after absorption of **TRUPOSEPT BA**. However, care should be taken that the skins do not dry out.

TRUPOSEPT BA is also suitable for spray application. Prepare a solution of approx. 12 - 15 g/l **TRUPOSEPT BA** and evenly spray 1 - 2 l. (according to skin size) of this solution on the skins hair side.

Safety and storage:

When handling **TRUPOSEPT BA**, normal safety precautions associated with the handling of chemicals should be observed. For more specific details please refer to our safety data sheets.

TRUPOSEPT BA can be stored for up to 24 months, if temperatures below 5 °C and above 40 °C can be avoided.

Use biocides safely. Always read the label and product information before use.