

# TRUPOSEPT<sup>®</sup> BA

## bactericide

Appearance:	yellowish liquid
Basis:	organic sulphur compounds
pH value (1 : 10):	approx. 10

### **Properties:**

**TRUPOSEPT BA** is an effective and safe bactericide. It is rapidly and uniformly absorbed by the skin surface.

**TRUPOSEPT BA** is extremely well suited for application during soaking and for short-term preservation (up to 5 days maximum).

**TRUPOSEPT BA** is a low-odour product. It should be used within pH range 5 - 10.

**TRUPOSEPT BA** is compatible with other soaking auxiliaries (e.g. **TRUPOWET<sup>®</sup>** products).

### **Application:**

#### **Soaking:**

0.05 - 0.1 % **TRUPOSEPT BA** (calculated on fresh or salted weight) is sufficient for a short soaking of 4 - 6 hrs.

0.1 - 0.2 % are usually applied for soaking overnight. The product is added at the beginning of soaking.

#### **Short-term preservation:**

A short-term preservation is usually required to preserve raw material over a week-end. Prior to the short-term preservation, washing should be carried out to remove dirt, dung and residual blood.

Then the preservation procedure (e.g. in drum) follows with 100 – 120 % water, 18 - 20 °C, plus 0.3 % **TRUPOSEPT BA**, run 45 - 60 mins., leave automatic with running 1 – 2 mins. every 2 – 3 hours.

This quantity (0.3 %) is sufficient for a preservation period up to three days under normal climatic conditions.

Should a longer preservation period be required quantities of **TRUPOSEPT BA** to be used have to be adjusted (plus 0.1 % per day!). Five days should not be exceeded.

Skins can be taken out of the drum approx. one hour after absorption of **TRUPOSEPT BA**. However, care should be taken that the skins do not dry out.

**TRUPOSEPT BA** is also suitable for spray application. Prepare a solution of approx. 12 - 15 g/l **TRUPOSEPT BA** and evenly spray 1 - 2 l. (according to skin size) of this solution on the skins hair side.

### **Safety and storage:**

When handling **TRUPOSEPT BA**, normal safety precautions associated with the handling of chemicals should be observed. For more specific details please refer to our safety data sheets.

**TRUPOSEPT BA** can be stored for up to 24 months, if temperatures below 5 °C and above 40 °C can be avoided.

Use biocides safely. Always read the label and product information before use.